



STEPS

STEP 1. 2 layer Torch-on System behind cavity batten fully supported by substrate plywood or timber. Finish 150mm over & beyond the parapet junction

STEP 2. Wall Underlay behind cavity. Finish over membrane

STEP 3. *Saddle Flashing over cavity batten, directly behind cladding, refer Fig12 E2/AS1

STEP 4. Cladding to seal to saddle flashing

STEP 5. Metal Cap flashing to seal to saddle flashing

1

PARAPET - SADDLE FLASHING

SCALE: NTS



The information and data contained herein are believed to be accurate and reliable. This information does not constitute a warranty and should be used in conjunction with the project specification document supplied by Allco Waterproofing Solutions Ltd. Please contact Allco Waterproofing Solutions Ltd with any questions or deviations from this information.
© Allco Waterproofing Solution Ltd

For Technical Advice Contact:
Web: www.allco.co.nz
Email: info@allco.co.nz
Telephone: 09 448 1185
Facsimile: 09 448 1186



DRAWN BY:
ALLCO

DATE:
07/2022

DRAWING REF:
CA-007A

REV:
1