

NOTE

USE HYDROTECH **FLEX-FLASH UN** - WHERE MINOR MOVEMENT OR CHANGE IN LEVEL DIRECTION OR DISSIMILAR MATERIALS OCCUR

OTHERWISE... US **FLEX-FLASH F** FOR CONCRETE TO CONCRETE TRANSITIONS

NOTE

HYDROTECH MUST BE LAID WITH A **PROTECTION LAYER** OVER THE MM6125. HYDROFLEX 30 or CASALI OLYMPIA or CASALI CAP SHEET

HYDROTECH MM6125 MEMBRANE SYSTEM


PROTECTION SHEET

1ST LAYER.

2ND LAYER.

FLEX-FLASH F

CONCRETE SUBSTRATE



1

HYDROTECH - WINDOW SILL / BALCONY SETDOWN - OPTION

SCALE: NTS

NOTE: THIS DETAIL IS NOT CODEMARK APPROVED



The information and data contained herein are believed to be accurate and reliable. This information does not constitute a warranty and should be used in conjunction with the project specification document supplied by Allco Waterproofing Solutions Ltd. Please contact Allco Waterproofing Solutions Ltd with any questions or deviations from this information.
© Allco Waterproofing Solution Ltd

For Technical Advice Contact:
Web: www.allco.co.nz
Email: info@allco.co.nz
Telephone: 09 448 1185
Facsimile: 09 448 1186



DRAWN BY: ALLCO
DATE: 06/19

DRAWING REF: H-001B

VER: 1.0