


SWELLTITE NOTES

BLOCK WALLS MUST BE FILLED PRIOR TO MEMBRANE APPLICATION

IF BACKFILL CANNOT BE APPLIED IMMEDIATELY, PROTECT MEMBRANE EDGES FROM PRECIPITATION WITH ALLCO SEAMTAPE.

IF BACKFILL CONTAINS SHARP OR IRREGULAR MATERIAL, COVER MEMBRANE WITH ALLCO APPROVED PROTECTION MATERIAL COURSE TO AVOID DAMAGE DURING BACKFILLING AND COMPACTION.

1 MASONRY WALL - CONTROL JOINT
SCALE: NTS



2 MASONRY WALL - COLUMN JOINT
SCALE: NTS



The information and data contained herein are believed to be accurate and reliable. This information does not constitute a warranty and should be used in conjunction with the project specification document supplied by Allco Waterproofing Solutions Ltd. Please contact Allco Waterproofing Solutions Ltd with any questions or deviations from this information.
© Allco Waterproofing Solution Ltd

For Technical Advice Contact:
Web: www.allco.co.nz
Email: info@allco.co.nz
Telephone: 09 448 1185
Facsimile: 09 448 1186



DRAWN BY: ALLCO	DATE: 06/23
DRAWING REF: V-W-03	REV: 4