


1 FLUSH FOOTING / WALL - ALLSHEET TO SWELLTITE LAP
SCALE: NTS

REFER ADJACENT DETAILS (1/2) FOR MEMBRANE PLACEMENT TO FOOTING


SEAL TAPE TO JUNCTION. OPTIONAL




4 FOOTING / WALL - POD FLOOR
SCALE: NTS

NOTE - PROVIDING PROTECTION OF ANY DPM PRODUCTS DURING BACKFILL IS SUGGESTED BUT NOT MANDATORY.

REFER ALLCO BACKFILL DOCUMENT FOR PROTECTION OPTIONS FOR ALLCO VOLCLAY MEMBRANES



2



3



The information and data contained herein are believed to be accurate and reliable. This information does not constitute a warranty and should be used in conjunction with the project specification document supplied by Allco Waterproofing Solutions Ltd. Please contact Allco Waterproofing Solutions Ltd with any questions or deviations from this information. If variances to published CETCO documentation occur, ALLCO detailing takes precedent. © Allco Waterproofing Solution Ltd

For Technical Advice Contact:
Web: www.allco.co.nz
Email: info@allco.co.nz
Telephone: 09 448 1185
Facsimile: 09 448 1186



DRAWN BY: ALLCO	DATE: 06/23
DRAWING REF: V-F-07	REV: 7