


NOTE
 USE HYDROTECH **FLEX-FLASH UN**
 - WHERE MINOR MOVEMENT OR
 CHANGE IN LEVEL DIRECTION OR
 DISSIMILAR MATERIALS OCCUR

OTHERWISE... US **FLEX-FLASH F**
 FOR CONCRETE TO CONCRETE
 TRANSITIONS

NOTE
 HYDROTECH MUST BE LAID
 WITH A **PROTECTION LAYER**
 OVER THE MM6125.
 HYDROFLEX 30 or CASALI
 OLYMPIA or CASALI CAP SHEET



1 HYDROTECH - WINDOW SILL / BALCONY SETDOWN
 SCALE: NTS



The information and data contained herein are believed to be accurate and reliable.
 This information does not constitute a warranty and should be used in conjunction with
 the project specification document supplied by Allco Waterproofing Solutions Ltd
 Please contact Allco Waterproofing Solutions Ltd with any questions or deviations from
 this information.
 © Allco Waterproofing Solution Ltd

For Technical Advice Contact:
 Web: www.allco.co.nz
 Email: info@allco.co.nz
 Telephone: 09 448 1185
 Facsimile: 09 448 1186



DRAWN BY: ALLCO	DATE: 06/19
DRAWING REF: H-001	VER: 1.1