

REFER ALLCO BACKFILL DOCUMENT FOR ACCEPTABLE BACKFILL

VOLCLAY SWELLTITE TO FOUNDATION WALL


ALLCO ALLGUARD PROTECTION BOARD

BENTOSEAL TO WALL / FOOTING JUNCTION

GOOD TRADE PRACTICE SUGGESTED OF TAPING DPM TO SWELLTITE

DPM TO FOOTING IS NOT PART OF THE VOLCLAY SYSTEM BUT IS GOOD TRADE PRACTICE

COIL DRAIN



1

FOOTING / WALL DETAIL - SWELLTITE LAP EXTENT TO FLUSH FOOTING

SCALE: NTS



The information and data contained herein are believed to be accurate and reliable. This information does not constitute a warranty and should be used in conjunction with the project specification document supplied by Allco Waterproofing Solutions Ltd. Please contact Allco Waterproofing Solutions Ltd with any questions or deviations from this information. If variances to published CETCO documentation occur, ALLCO detailing takes precedent. © Allco Waterproofing Solution Ltd

For Technical Advice Contact:  
 Web: [www.allco.co.nz](http://www.allco.co.nz)  
 Email: [info@allco.co.nz](mailto:info@allco.co.nz)  
 Telephone: 09 448 1185  
 Facsimile: 09 448 1186



DRAWN BY: ALLCO	DATE: 10/23
--------------------	----------------

DRAWING REF: V-F-08C	REV: 1
-------------------------	-----------